



**Monteringsværktøj til rørclips**  
**Vrn. 33 9401 800**

1. Handle
2. Handle guide
3. Clips guide
4. Weight
5. Supportive stand
6. Tacker body
7. Inspection slot





GOTTFRED PETERSEN A/S



#### Information about the tool

Compatible with tacker staples ( welded and tape-glued ) in sizes: 35mm, 40mm, 50mm, 60mm.

The tool is made of aluminium, fitted with a steel pusher.

The tool is equipped with an inspection slot and supportive stand.

#### Assembly, Supportive Stand

The tool is fully functional upon reception by the customer.

The tacker does not require further assembly, aside from fitting the supportive stand into the slots.

The slots for the supportive stand are found on both sides of the tacker gun.

Fit the supportive stand by pushing the bent rods into the slots.



#### Inspection slot

If a staple becomes stuck, turn the knob to the side to release the slot - now you are able to remove the stuck clips.

Put the slot up and turn the knob upwards to lock it.



#### Tacker Loading

To load the tacker, remove the weight from the clip guide and load the clips onto the guide.

After the clips have been loaded, put the weight back onto the clips guide to push them forward.